

Estimated Time: 10–15 Minutes

Read fully before starting. Follow steps in order.

Before you start

- Install this kit in one home only. Do not reuse for another client.
- Plug devices directly into wall outlets.
- Do not use outlets controlled by wall switches.
- Do not leave the home until activation is confirmed.

6-Digit Kit ID:

STEP 1

Install the LTE Router

The router provides Internet for the system.

1. Gently bend the antenna arm so all 3 antennas are pointing up.
 2. Place router in a central location, ideally on an elevated surface near a window, at least 2 feet from other electronic devices (TV, cable box, other Wi-Fi router, power supply).
 3. Plug the power cord into the router.
 4. Plug the adapter into a wall outlet.
 5. Power light should turn on.
 6. If no power light:
 - Confirm outlet has power
 - Try a different outlet
 7. Wait 2–3 minutes for router to connect before proceeding to Step 2.
-

STEP 2

Install the Hub

The hub connects all sensors.

1. Place hub in the same room as the router and central to where the door, fridge and humidity sensors will be installed.
2. Plug directly into a wall outlet.

Light behavior:

- Flashing red = connecting
- Solid blue = connected

If red for more than 5 minutes move the hub closer to router.

Hub is ready when light is solid blue.

STEP 3

Install Wi-Fi Motion Plugs

Plugs are labeled:

- Living Room
- Bedroom
- Bathroom
- Kitchen

For each plug:

1. Do NOT press or hold side button.
2. Plug into a wall outlet in the matching room.
3. Avoid placing behind large furniture or appliances.
4. If no outlet is available in the room, use nearest hallway or adjacent outlet.

Light behavior:

- Green = connecting
- Light off after ~1 minute = connected

If green light stays on more than 5 minutes move plug to an outlet closer to the router.

STEP 4

Install Door & Fridge Sensors

Sensors are labeled:

- Front Door (or primary door used to exit/enter the home)
- Exit Door (secondary door ex: garage/back/patio)
- Fridge Door

Each sensor should be installed on the moving part of the door. For each sensor repeat the steps below:

1. Ensure the surface is clean and dry.
 2. Pull clear activation strip (light will blink).
 3. Remove adhesive backing.
 4. Mount on upper half of door, positioned on the handle side.
 5. Press sensor firmly for 10 seconds to adhere to the surface.
-

STEP 5

Install Humidity Sensor

Install in the **primary bathroom**.

1. Mount on the wall near the shower or bath, approximately 6 feet high.
 2. Ensure the sensor is NOT in direct water spray.
 3. Ensure the surface is clean and dry.
 4. Pull activation strip (light will blink).
 5. Remove adhesive backing.
 6. Press sensor firmly for 10 seconds to adhere to the surface.
-

STEP 6

Activate the System

Call: 1-888-667-1224

Provide:

- 6-digit Kit ID
- Client name
- Installation address

Stay in the home until support confirms:

- Router online
- Hub connected
- All sensors reporting

Do not leave until activation is confirmed.

Final check before leaving

- ✓ Router light on
- ✓ Hub solid blue
- ✓ All motion plugs installed. No light illuminated.
- ✓ All door sensors installed
- ✓ Humidity sensor installed
- ✓ Activation confirmed

Support

Phone: 1-888-667-1224

Email: support@joinlifeguard.com